

- 1.** Take out the exhaust silencer, bracket, and M5 nut, spring washer, and bolt from the box. Fix the silencer and bracket together by placing the M5 bolt through the lowest hole on the brackets curved edge, and placing it through the pre-drilled hole in the silencer. Attach and tighten the M5 nut on the end of the bolt to secure it all together.
- 2.** The silencer can either be installed at the end of the exhaust or in the middle. To attach at the end, simply use a hack saw to remove the exhaust end cap (if one is attached) before attempting to fit the exhaust. To attach in the middle of the exhaust, simply cut the exhaust in half, or where you want the silencer to be installed.
- 3.** Insert the exhaust silencer into the end of the exhaust pipe, or into the centre depending on step 2. Secure in position with jubilee clips (not included). Orientation of the silencer does not matter.
- 4.** Mark and drill two holes into an appropriate mounting location on the vehicles chassis. Then use the two self-tappers provided to affix the exhaust bracket in place.



MV Heating (UK) Limited
Unit 6, Second Avenue Business Park, Millbrook, Southampton, Hants SO15 0LP
Telephone: 023 8052 2345 Fax: 023 8052 8808 Email: sales@mvheating.co.uk
www.mvheating.co.uk

