


2-Way Rocker On/Off Switch



2-Way Rocker On/Off Switch:

When a room thermostat is installed it will override the rocker switch completely. The room stat will be used to control the heater.

To use the rocker switch, put the thermostat into 'frost mode' or remove the thermostat from power.

The switch will then operate normally – The top switch (position 1) is the OFF position, and the heater will remain off.

The bottom position (position 2) will turn the heater ON, and the heater will remain on until switched off.

2-Way Press On/Off Switch




2-Way Press On/Off Switch:

When a room thermostat is installed it will override the press switch completely. The room stat will be used to control the heater.

To use the press switch, put the thermostat into 'frost mode' or remove the thermostat from power.

The switch will then operate normally – Press in to switch the heater on, and depress to switch it off.



ON/Off Switch



Heatmiser
Slimline B
contacts

B = Black
U = Blue